

Recording

Watching One Show While Recording Another at the Same Time

(This function requires the use of two TV streams and two RG remotes)

	TV-1
TV tuned to	Channel 3
VCR tuned to	Channel 6

- After programming TV and VCR to the above, use the Stream 1 remote control to select program you wish to record.
- Press the record button on VCR
- Press the VCR/TV button off on your VCR remote
- Change the channel on your TV to channel 7. Use the remote control for Stream 2 to select program you wish to watch

Timed Program Recording While at Home or Away With TV Off

Set your VCR to the correct time and date by as specified by the manufacturer. Also, follow the VCR instructions for timed program recording.

	TV-1
TV tuned to	Channel 6
VCR on	Channel 3

- Program your VCR to record Channel 6
- Use the RG remote to auto tune

Auto tuning with your RG remote control

- Go to guide
- Find the show and time slot you wish to record, press select.
- Right arrow over to .actions., press select
- Arrow down to schedule auto tune, press select
- Determine if it is a one-time, daily or once-a-week recording and press select
- Auto tune will be accepted
- Exit out of programming mode

IMPORTANT: If you wish to record a program while the TV is turned off: Turn off the TV using the TV power button. (Do not use the green power button on the RG remote.)